




# Wire Brushes

Solid ring construction ensure that the brushes run smoother and longer with less vibration.



**Fine** wire for polishing steel, copper and brass. Preparation of metal surfaces for soldering, welding and painting. Light rust and scale removal. Plastic flash removal.  
**Coarse** for preparation of metal and rubber surfaces for adhesive bonding. Removal of rust, scale, slag, and paint. Deburring, light grinding and carbon cleaning. Plastic flash removal.  
**Encapsulated** for roughening metal and surface cleaning; removal of heavy rust, weld splatter and automotive gasket removal.

## End Brush



SIZE	WIRE	SHANK SIZE	SAFE MAX. RPM SPEED	CARDED PART NO.	STD. PACK
1"	Coarse	1/4"	20,000	76201	2

## Cup Brush



SIZE	WIRE	SHANK SIZE	SAFE MAX. RPM SPEED	CARDED PART NO.	STD. PACK
1-3/4"	Coarse	1/4"	4,500	76211	2
1-3/4"	Fine	1/4"	4,500	76213	2
2-3/4"	Coarse	1/4"	4,500	76221	2
2-3/4"	Fine	1/4"	4,500	76223	2

## Radial Wire Brush




SIZE	WIRE	SHANK SIZE	SAFE MAX. RPM SPEED	CARDED PART NO.	STD. PACK
2"	Coarse	1/4"	4,500	76411	2
2"	Fine	1/4"	4,500	76413	2
2-1/2"	Coarse	1/4"	4,500	76421	2
2-1/2"	Fine	1/4"	4,500	76423	2
3"	Coarse	1/4"	4,500	76431	2
3"	Fine	1/4"	4,500	76433	2
4"	Coarse	1/4"	4,500	76441	2
4"	Fine	1/4"	4,500	76443	2

## Encapsulated Wire Brush




SIZE	WIRE	ARBOR	SAFE MAX. RPM SPEED	CARDED PART NO.	STD. PACK
2"	Encap.	1/2"	20,000	76620	2
3"	Encap.	1/2"	20,000	76630	2

## Wire Wheels



SIZE	WIRE	ARBOR	SAFE MAX. RPM SPEED	CARDED PART NO.	STD. PACK
4"	Coarse	1/2"	4,500	76841	2
4"	Fine	1/2"	4,500	76843	2
5"	Coarse	1/2" / 5/8"	4,500	76851	2
5"	Fine	1/2" / 5/8"	4,500	76853	2
6"	Coarse	1/2" / 5/8"	4,500	76861	2
6"	Fine	1/2" / 5/8"	4,500	76863	2

## Wire Wheel Adapter



FITS ARBOR	APPLICATION	CARDED PART NO.	STD. PACK
1/2"	Converts 1/2" arbor to a 1/4" shank.	76800	2